

**EN - Addendum to manual MC824H**

**IT - Addendum al manuale MC824H**


**FR - Addenda au manuel MC824H**

**ES - Apéndice al manual MC824H**

**DE - Addendum zur manuellen MC824H**

**PL - Załącznik do podręcznika MC824H**

**NL - Addendum bij de handleiding MC824H**



IS0533A00MM\_19-07-2017

<b>EN</b>	<b>Chapter 3: in paragraph 3.7 replace Table 3 with the table given here to the side</b>
<b>IT</b>	<b>Capitolo 3: nel paragrafo 3.7 sostituire la Tabella 3 con quella riportata a lato</b>
<b>FR</b>	<b>Chapitre 3 : remplacer au paragraphe 3.7 le tableau 3 par le tableau indiqué ci-contre</b>
<b>ES</b>	<b>Capítulo 3: en el apartado 3.7 sustituir la Tabla 3 con la de al lado</b>
<b>DE</b>	<b>Kapitel 3: Im Abschnitt 3.7 die Tabelle 3 durch die nebenstehende Tabelle ersetzen</b>
<b>PL</b>	<b>Rozdział 3: w paragrafie 3.7 zastąpić Tabelę 3 tą, zamieszczoną obok</b>
<b>NL</b>	<b>Hoofdstuk 3: in paragraaf 3.7 moet Tabel 3 worden vervangen door de tabel hiernaast</b>

<b>TABLE 3</b>		
<b>Gearmotor type</b>	<b>Set from control unit (led)</b>	<b>Set from Oview (label)</b>
MB4024 - MB5024 - HY7024 - HY7124	<b>L1</b>	MB4024
MFAB3024	<b>L2</b>	ME3024
TO4024 - XFAB2124 - LFAB4024	<b>L3</b>	TO4024
TO5024 - TO5024I	<b>L4</b>	TO5024
TO7024 - TO6024HS	<b>L5</b>	TO7024
BFAB5024	<b>L6</b>	BM5024
METROELITE - MFAB3024HS - TO5024HS	<b>L7</b>	METROE
WINGOELITE - WG3524HS - LFAB4024HS - TTN3724HS - TTN6024HS	<b>L8</b>	WINGOE