

How to program a code into your new LTX:

First make sure the LTX selected matches the frequency of your original TX.

- a. Yellow button = 403.55MHz
- b. Orange button = 433.92MHz

With both the LTX and the original TX in hand:

1. Press and hold required button on LTX while watching its LED.
2. When LED extinguishes, keep holding button and place the front of the LTX against the front of the original TX.
3. Press and hold the original TX button you want to copy until the LED on the LTX begins flashing.
4. Release both the LTX and the original TX buttons.

Repeat 1-4