


For motor series “Nomat H”, type: NM28601HMT; NM46601HMT; NM65601HMT; NM90601HMT

### **2.1 Electrical connections**

Wires change colors:



Black = Phase  
 White = Neutral  
 Yellow/Green , Green = Earth

### **Technical characteristics**


change value:

.....  
 Nominal operating time : see the technical data on the label attached to each model  
 Work cycle : see the technical data on the label attached to each model  
 .....  
 Length of connection cable : 12 ft  
 .....

Para el motor de la serie “Nomat H”; tipo: NM28601HMT; NM46601HMT; NM65601HMT; NM90601HMT

### **2.1 Conexiones eléctricas**

Cambio colores conductores



Negro = Fase  
 Blanco = Neutro  
 Amarillo/Verde , Verde = Tierra

### **Características técnicas**

Cambio valores:

.....  
 Tiempo nominal de funcionamiento : Véanse datos técnicos en etiqueta de cada modelo  
 Ciclo de trabajo : Véanse datos técnicos en etiqueta de cada modelo  
 .....  
 Longitud del cable de conexión : 12 ft  
 .....

This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions:

- 1) this device may not cause harmful interference, and
- 2) this device must accept any interference received, including interference that may cause undesired operation.

**Warning:**

changes or modifications made to this equipment not expressly approved by **NICE S.p.A.** may void the FCC authorization to operate this equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.